INFORMATION GUIDE DFG700 GRINDER



PLEASE CHECK THE FOLLOWING UPON DELIVERY



FLY LEAD



DUST EXTRACTION ADAPTOR







ADJUSTABLE WEIGHTS

TO RESERVE ANY OF OUR TOOLS OR MACHINES CALL US ON 01245 399150



ACCESSORIES KIT

1 SCREWDRIVER 1 SMALL ALLEN KEY 1 LARGE ALLEN KEY 1 SPIRIT LEVEL 1 SAFETY KIT 4 SPARE BOLTS 5 FUSES 4+PCD SPARE BOLTS (SMALLER BOLTS)



UNDERNEATH THE MACHINE TIP THE MACHINE BACK TO CHECK:

1. THERE ARE 4 BOLTS ON EACH HOLDER 2. THERE IS NO SET CONCRETE UNDER THE MACHINE



3. THE RUBBER COUPLINGS UNDERNEATH ARE NOT BROKEN OR DAMAGED

TO START THE MACHINE



ENSURE THE RED SWITCH IS SET TO 'ON' AND THE FUSE BOX IS SHUT PROPERLY



A. ENSURE THE RED BUTTON IS PULLED OUT

(RED LIGHT SHOULD BE ON)

B. PRESS THE GREEN BUTTON

(GREEN LIGHT SHOULD BE ON)

C.

- TILT THE MACHINE BACK
- HOLD THE TRIGGER IN
- PRESS THE GREEN BUTTON ON THE HANDLES

(MAKE SURE BLADES NOT TOUCHING FLOOR)

NOTES (PLEASE READ BEFORE USING MACHINE)

- IF THE RED BUTTON IS PRESSED OR THE RED SWITCH IS TURNED OFF WHILST THE MACHINE IS PLUGGED IN THEN THE MACHINE WILL NOT START FOR APPROX. 15 MINUTES - IF THE MACHINE IS USED WET, ENSURE ALL THE SLURRY AND DEBRIS IS WASHED OUT/ REMOVED FROM THE MACHINE BEFORE IT SETS (DO NOT GET THE MOTOR OR ELECTRICAL BOX WET)

- INSIDE THE ELECTRICAL BOX THERE ARE 2 FUSES WHICH WILL STOP THE MACHINE FROM WORKING IF TRIPPED. NEVER OPEN THE ELECTRICAL BOX WHILST THE MACHINE IS PLUGGED IN

- IF THE ELECTRICAL BOX IS NOT CLOSED PROPERLY THEN THE MACHINE WILL NOT START DUE TO THE MICRO SWITCH INSIDE

- YOU CAN MOVE THE ADJUSTABLE WEIGHTS TO THE FRONT OR BACK OF THE MACHINE TO INCREASE/DECREASE DOWN PRESSURE AND THE AGGRESSIVENESS OF THE MACHINE

